


Between Series Part Numbering



Between-Series Adapter


BNC - M Adapter



BNCJ-MJ

Product Number	BNC	M
BNCP-MP	Plug	Plug
BNCP-MJ	Plug	Jack
BNCJ-MP	Jack	Plug
BNCJ-MJ	Jack	Jack


BNC - SMA Adapter



BNCJ-SMAP

Product Number	BNC	SMA
BNCP-SMAP	Plug	Plug
BNCP-SMAJ	Plug	Jack
BNCJ-SMAP	Jack	Plug
BNCJ-SMAJ	Jack	Jack


BNC - TNC Adapter



BNCP-TNCJ

Product Number	BNC	TNC
BNCP-TNCP	Plug	Plug
BNCP-TNCJ	Plug	Jack
BNCJ-TNCP	Jack	Plug
BNCJ-TNCJ	Jack	Jack


N - SMA Adapter



NJ-BNCJ

Product Number	BNC	SMA
NP-SMAP	Plug	Plug
NP-SMAJ	Plug	Jack
NJ-SMAP	Jack	Plug
NJ-SMAJ	Jack	Jack



N - M Adapter



NJ-MJ

Product Number	N	M
NP-MP	Plug	Plug
NP-MJ	Plug	Jack
NJ-MP	Jack	Plug
NJ-MJ	Jack	Jack


N - BNC Adapter



NJ-BNCJ

Product Number	BNC	BNC
NP-BNCP	Plug	Plug
NP-BNCJ	Plug	Jack
NJ-BNCP	Jack	Plug
NJ-BNCJ	Jack	Jack

N - TNC Adapter



NJ-TNCP

Product Number	N	TNC
NP-TNCP	Plug	Plug
NP-TNCJ	Plug	Jack
NJ-TNCP	Jack	Plug
NJ-TNCJ	Jack	Jack

Specifications subject to change without notice. Consult Sam Woo Electronics for the latest specifications.